

# grotanol<sup>®</sup> SR 2

## Microbiocidal system cleaner for circulation systems and production plants

- High concentrated and free of water
- Effective even in very low use-concentrations
- Excellent cleaning and microbiocidal effect
- Broad, balanced spectrum of effect against bacteria, yeasts and moulds
- Good immediate effect
- Good anticorrosion properties
- Low foaming
- Usable for all steel, non-ferrous and aluminium alloys
- Suitable for low to medium alcalic medium (pH 8 - 11)
- Fulfils the requirements of the EN 1275
- Contains no organically bound chlorine (has no effect on the AOX value)

Active substance		
EINECS-Name:	CAS-No.	EC-No.
3,3'-Methylenebis[5-methyloxazolidine]	66204-44-2	266-235-8
Pyridine-2-thiol-1-oxide, sodium salt	3811-73-2	223-296-5

Other compounds	
non-ionic surfactants	> 15 - < 30 %

Physico-chemical properties	
Colour	light yellow - yellow
Form	Liquid
Odour	nearly odourless
Density (20 °C)	1.045 - 1.057 g/ml
Refractive index (20 °C)	1.462 - 1.474
Freezing point	< -18 °C
Initial boiling point	> 100 °C
Flash point (ISO 2719)	> 100 °C
Flow time (DIN 53211 - 20 °C)	ca. 40 s
Viscosity (20 °C)	162 mPa*s
Water solubility (20 °C)	completely miscible
VOC-Content to Directive 2004/42/EC	73 %
pH (10 g/l in water)	ca. 10

Fields of application		
The recommended use levels relate to the total formulation in each case. The values given are recommended guidelines. The optimum use-concentration depends on the degree of soiling.		
<b>Use biocides safely. Always read the label and product information before use.</b>		
<b>Recommended dosage</b>		
Metalworking fluid plants, production plants, circulating systems and equipment	2.5 - 7.5 g/kg	(0.25 - 0.75 %)

Indications for use	
General Information	Depending on the degree of soiling, grotanol <sup>®</sup> SR 2 is used 0.25 % - 0.75 % in an aqueous solution. In order to achieve an optimum cleaning effect, a contact time of at least 6 - 24 hours is recommended.
Metal working fluid systems	In metalworking fluid systems grotanol <sup>®</sup> SR 2 can be added to the emulsion before the last shift begins and allowed to circulate. In general, work can be continued while the system cleaner is being used. Emulsifiers carry away the tramp oil and loosened dirt in the system. To prevent blockages, inspection of filters and overflows is advisable. Together with the microbiological sanitization, i.e. germ reduction in the system, there is a very good cleaning effect. After only 6 - 24 hours the cleaning is finished and the system is sanitized due to the excellent microbiocidal efficacy of grotanol <sup>®</sup> SR 2. Please note that in cases of especially heavy contamination it is advisable to combine chemical and mechanical system cleaning. At the end of the residence time, which usually lasts for one shift, the metalworking fluid dilution containing the system cleaner can be discharged, split and disposed of as usual.

Microbiological efficacy	
Due to the combination of bactericidal and fungicidal active agents, grotanol <sup>®</sup> SR 2 acts against a broad spectrum of bacteria, moulds and yeasts.	

# grotanol<sup>®</sup> SR 2

Compatibility*		
	compatible	to be avoided
aqueous dilution (0.5 %)	plastics, sealants, stainless steel, steel, aluminium, zinc, copper, brass, bronze	No significant difference to water
Further information	From the available test results, it can be concluded that the addition of grotanol <sup>®</sup> SR 2 has virtually no influence on the medium to be preserved.	

\*Compatibility has to be proved in each case

Labelling	
Hazard statements	H302 + H332, H314, H410, Toxic by eye contact.
Precautionary statements	P273, P280, P301 + P330 + P331, P303 + P361 + P353, P304 + P340, P305 + P351 + P338, P310
Labelling	Danger - GHS05 (Corrosion), GHS07 (Exclamation mark), GHS09 (Environment)
For further hazard instructions and safety advice please refer to the actual material safety data sheet.	

Environmental information
At a sufficient degree of dilution, all components of grotanol <sup>®</sup> SR 2 are completely biodegradable. Dilutions of grotanol <sup>®</sup> SR 2 do not normally interfere with the operation of waste water treatment plants. grotanol <sup>®</sup> SR 2 contains no organic chlorine compounds, so that there is no effect on the AOX as a result of grotanol <sup>®</sup> SR 2 in the waste water. The canisters and drums used by schülke are made of polyethylene (HDPE) and are labelled accordingly. The 1000 kg containers are covered by a return scheme that ensures collection of the used containers free of charge and appropriate reuse all over Europe. The labels are made of PE. schülke packaging materials contain no PVC and can be recycled. For further information please ask for our detailed environmental report.

Listings and approvals of active ingredients
EINECS / ELINCS (Europe)
TSCA (USA)
ECL (Korea)
DSL / NDSL (Canada)
AICS (Australia)
PICCS (Philippines)
IECSC (China)
Fullfills the requirements of the TRGS 611 (Germany)

Transport & Storage	
Dangerous goods	Yes
UN number	3267
Packaging group	III
Package sizes	10 kg, 200 kg, 1000 kg
Shelf life	24 months
Storage	Protect from frost, heat and direct sunlight. Store at room temperature in the original container.

## schülke subsidiaries:



### Belgium

S.A. Schülke & Mayr  
Belgium N.V.  
1130 Brussel  
Tel. +32-2-479 73 35  
Fax +32-2-479 99 66

### Netherlands

Schülke & Mayr Benelux B.V.  
2031 CC Haarlem  
Tel. +31-23-535 26 34  
Fax +31-23-536 79 70

### China

Schülke & Mayr GmbH  
Shanghai Representative Office  
Shanghai 200041  
Tel. +86-21-62 17 29 95  
Fax +86-21-62 17 29 97

### Switzerland

Schülke & Mayr AG  
8003 Zürich  
Tel. +44-466 55 44  
Fax +44-466 55 33

### France

Schülke France SARL  
94250 Gentilly  
Tel. +33-1-49 69 83 78  
Fax +33-1-49 69 83 85

### United Kingdom

Schülke & Mayr UK Ltd.  
Sheffield S9 1 AT  
Tel. +44-1142-54 35 00  
Fax +44-1142-54 35 01

### Italy

Schülke & Mayr Italia S.r.l.  
20148 Milano  
Tel. +39-02-40 26 590  
Fax +39-02-40 26 609

### Other Distributors:

Argentina · Australia · Austria · Belarus · Benin · Brazil · Bulgaria · Canada · Croatia · Czech Republic · Denmark · Egypt · Estonia · Finland · Ghana · Greece · Hong Kong · Hungary · India · Indonesia · Iran · Israel · Japan · Jordan · Korea · Kuwait · Latvia · Lebanon · Lithuania · Macedonia · Malaysia · New Zealand · Nigeria · Norway · Oman · Philippines · Poland · Portugal · Russia · Saudi Arabia · Singapore · Slovakia · Slovenia · South-Africa · Spain · Sweden · Syria · Taiwan · Thailand · Turkey · Ukraine · United Arab Emirates · USA · Vietnam · Yemen

Our recommendations regarding our products are based on in-depth scientific testing in our Research Department; they are given in good faith, but no liability can be derived from them. It is the responsibility of the final product manufacturer to assure that claims made for the final product are in conformance with all applicable local laws. In other respect our Conditions of Sale and Supply apply.

**Schülke & Mayr GmbH**  
22840 Norderstedt  
Germany  
Tel. +49 40 52100-0  
Fax +49 40 52100-244  
[www.schuelke.com](http://www.schuelke.com)  
sai@schuelke.com